

INSTALLATION GUIDELINES and GENERAL INFORMATION:

- 1. All low voltage wiring is #22 AWG, unless otherwise noted.
- 2. Check for shorts and/or grounds before connecting transformer to IA543 or PK543A amplifier.
- Install transformer at least 3 feet (1 meter) away from IA543 or PK543A amplifier.
- 4. Observe all local and national electrical and building codes.
- 5. All terminals connections shown may not be in the order that they appear on the equipment.
- 6. Any terminals that are shown without connections are not used for this application.
- 7. Only one (1) indoor station should be used at one time.



Email:info@alphacommunications.com

TYPICAL WIRING INSTRUCTIONS For the IA543 or PK543A Amplifier with IS204ATS or IS543TS With up to Three (3) or Four (4) 4-Wire Inside IS204ATS or IS543TS Intercom Stations connected in parallel.